

# Mounting Instructions – T44

**BEFORE STARTING THE INSTALLATION, PLEASE BE SURE TO READ ALL SAFETY INFORMATION FROM STENNER CLASSIC SERIES INSTALLATION AND MAINTENANCE MANUAL.**

## Supplement to Stenner Classic Series Installation – Mount Pump

1. Mount pump within 10' from the point of injection and approximately 1'-2' above the solution container.
2. Use the mounting bracket with extension as a template to mark the location and drill the 3 pilot holes. **A**
3. Use a suitable fastener and anchor the mounting bracket with extension to the wall.
4. Slide the pump into the mounting bracket; the pump head will rest in the extension as shown in **B**. The extension provides support and allows the pump to be horizontally mounted with all tube connections pointed downward as shown in **C**.
5. Continue with installation using the Classic Installation Manual.

